




## Installation Techniques - Link-Seal® Modular Seals



1. Center the pipe, cable or conduit in wall opening or casing. Make sure the pipe will be adequately supported on both ends. Link-Seal® modular seals are not intended to support the weight of the pipe.



2. Loosen rear pressure plate with nut just enough so links move freely towards and away from each other - connect both ends of belt.




3. Check to be sure all bolt heads are facing the installer. Extra slack or sag is normal. Do not remove links if extra slack exists. **Note:** On smaller diameter pipe, links may need to be stretched.



4. Slide belt assembly into annular space. For larger size belts, start inserting Link-Seal modular seal assembly at the 6 O'Clock position and work both sides up toward the 12 O'Clock position in the annular space.



5. Start at 12'O Clock and tighten bolt until rubber begins to "bulge". Do not tighten any bolt more than 4 turns at a time. Continue in a clockwise manner until links have been uniformly compressed. (Approx. 2 or 3 rotations)



6. Make 2 or 3 more passes at 3 turns per bolt, tightening all bolts clockwise.



7. If the seal doesn't appear to be correct using the instructions provided, **Call PSI at 800-423-2410.**



**Installation Notes:** The Link-Seal® modular seal bolt heads are usually recessed below the wall opening or the edge of casing pipe and therefore a socket or offset wrench must be used.  
Hand Tools: Use 5/16" hex or #6 screwdriver for LS-200. 1/2" hex requires 3/8" drive socket wrench. 9/16" and 3/4" hex requires 1/2" drive socket wrench. (Tools not provided.)

**Always Wear Safety Equipment  
When Installing Link-Seal® modular seals!**

**Always Wear Safety Equipment When Using Link-Seal® Modular Seals!**



### Link-Seal® Modular Seal - Do's

1. Make sure pipe is centered.
2. Install the belt with the pressure plates evenly spaced.
3. Install the exact number of links indicated in sizing charts.
4. Check to make sure pipe is supported properly during backfill operations.
5. Make sure seal assembly and pipe surfaces are free from dirt.



### Link-Seal® Modular Seal - Don'ts

1. Don't install the belt with the pressure plates aimed in irregular directions. (Staggered)
2. Don't install Link-Seal® modular seals with spiral weld pipe.
3. Don't torque each bolt completely before moving on to the next.
4. Don't use high speed power tools (450 rpm or less)
5. Do not use power tools with Link-Seal modular seal 316 stainless steel bolts.