



NOTES

All removal and replacement of brickwork is to be done carefully, to ensure no destabilisation of the walls.

Grind off any "sharps" from the outer edge of the lower bricks, so that the membrane is not at risk of puncture from beneath.

Ensure that the lower course of brickwork gives smooth full support to the membrane when the wall loads are reapplied. If necessary, mortar the top surface of the bricks smooth. This especially applies to extruded bricks.

© WOLFIN MEMBRANES AUSTRALIA PTY LTD

TYPICAL RETROFIT FLASHING

Scale: 1: 5

Date: Jan 2010

Dwg No: **SD - 11**